




1. Getting to Know Your Radio



Buttons	Descriptions
Menu/Power	- Press to enter Menu and scroll through the menu screen. - Press and hold for two seconds to turn on or off the radio.
+ and -	- Press to adjust the volume level. - Press to change the settings or trigger action in the menu screen.
PTT	- Press and hold to talk, release to stop transmission. - Press to exit menu screen and return to home screen.
Easy Pairing	Copy channel and code settings from radio A to radio B. - Radio B—Hold the button until you hear a beep. The radio is ready to be paired. Multiple radios can be paired simultaneously. - Radio A—Hold the button until you hear a double beep. The radio broadcasts channel and code settings for other radios to pair.


2. Setting up Your Radio

Installing and Charging the Battery




- Observe the polarity before installing the battery.
- Charge the battery using the desktop charger or USB. Charging is completed when the battery icon on the radio stops blinking. Charging takes up to 8 hours.

Inserting and Removing Belt Clip



Attaching Short Lanyard



Turning your Radio On and Off

To turn the radio on or off, hold the Power/Menu button until the display turns on or off.

Channel and Codes

- Set your radios with the same channel and code setting to enable communication with other radios.
- The channel setting controls the radio frequency. To avoid jamming, select a channel that is not used by others in your area. See table in Section 3, "Scan" for more information on selecting unused channel.
- The code setting on the transmitting and receiving radios need to match, otherwise the receiving radio blocks the received signal. This feature helps you to mute unwanted voices from other radio users transmitting on your channel.
- When code is set to zero, radio does not block any signal and everything that is picked up on the channel is sent to the speaker. Motorola Solutions recommends setting your code to zero when using T38 with radios that do not support the code feature. See Section 3, "Navigating the Menu Pages" for detailed instructions on how to change settings.
- Channel and code settings can be copied from one radio to multiple radios simultaneously with a shortcut feature called Easy-Pairing. See table in Section 1, "Easy Pairing" for instruction on how to copy channel and code settings.

Call Tone

When you send a Call Tone, the receiving radio sounds a tone similar to phone ringing tone.

Scan

Radio scans for voice activity by cycling through the channels. When signals are detected, the signal is sent to the speaker. This feature allows you to find which channel is being used by other groups and have heavy traffic. This helps you to avoid the busy channels when deciding which channel to use for your group.

Monitor

You can hear everything including noise on your current radio channel. This feature allows you to monitor a channel for weak signals.


Roger Tone

This feature adds a beep to mark the end of a transmission when you release the PTT button. When the receiver hears the roger tone, it is a confirmation that complete message has been received.

Weatherproof

This radio is weatherproof to IP54 standards. The radio is resistant to occasional splash of water only when the battery and connector covers are sealed. Do not expose the radio to water for extended period of time. Do not submerge the radio in water.

3. Navigating the Menu Pages



Use the **Menu** button to scroll through the menu screen. Press **PTT** to exit any screen and return to home screen.

Menu Screen	Use the + or - button to perform the following actions:
Call Tone 🎵	Start or stop Call Tone transmission.
Monitor MON	Start or stop monitoring the air-wave. You can hear signals transmitted on the channel setting of your radio. If there is no signal, you can hear static.
Scan Z	Start or stop scanning the air-wave. Radio scans all the channels one after another. When a signal is detected, you hear the signal on the speaker and the radio displays the channel of the detected signal.
Adjust VOX VOX/iVOX	To change the Voice Operated Transmission (VOX) setting, select OFF or L1 to L3. L3 being the most sensitive, use it in quiet environments.
Adjust Roger Tone 🔔	Enable or disable the roger tone. Roger tone is a beep tone that you hear when PTT is released.
Adjust Channel (Channel number blinks)	Use + or - buttons to change the radio channel setting.
Adjust Code (Code number blinks)	Change the radio code setting.
Adjust Auto Key Lock	Change the Auto Key Lock setting.

Battery Information

This radio is equipped with a rechargeable Li-Ion battery.

The rated battery life is measured under industrial standard 5-5-90 duty cycle under lab conditions. (5% of the time transmitting, 5% receiving with speaker on, 90% waiting for incoming call.)

To maximize your battery performance and lifespan, avoid depleting your battery completely. When stored for an extended period, fully charge the battery first and remove the battery from the radio before storage.

When charging a completely empty battery it will take the radio up to a few minutes to 'wake up' and provide charging feedback, this is normal behavior.

Note: Note: Connect the USB charger to a nearby and easily accessible wall power outlet. Turn off radio before charging.

	Caution: Use only Motorola Solutions approved batteries. Risk of explosion if the battery is replaced by an incorrect type.
--	--

Push-to-Talk Time-out Timer

To avoid air-wave traffic congestion, transmission ends after one minute even if the PTT button is still pressed. To reset the timer, release the PTT button briefly.

4. Using Your Radio

Talking/Transmitting

- Press and hold the **PTT** button, then start talking into the microphone.
- Release the **PTT** button to stop transmission.

Note: Do not press the **PTT** button when others are talking. When more than one radio transmits on the same channel, the air-wave is jammed and all transmissions are lost.

Listening/Receiving

- The radio speaker receives signal automatically if radio is set to the same channel and code as the transmitting radio.
- Ensure the speaker volume is set to an appropriate level.

Adjusting Speaker Volume

- Press + or - from the home screen.

Auto Key Lock

- When Auto Key Lock feature is enabled, the 3 front buttons will be locked after 10 seconds of inactivity.
- To unlock the 3 front buttons, press and hold any of them for 2 seconds.

Using Headsets

- When a headset is connected to the radio, radio speaker is disabled. You need to wear the connected headset to monitor and receive messages.
- If your headset has **PTT** button, you can use the button to make a transmission with the microphone on the headset.
- You can still use the **PTT** button on the radio to make a transmission with the microphone on the radio.

Channel and Frequencies

Channel	Frequency (MHz)
1	446.00625
2	446.01875
3	446.03125
4	446.04375
5	446.05625
6	446.06875
7	446.08125
8	446.09375

Additional Information

Internal Voice Operated Transmission (iVOX)/Voice Operated Transmission (VOX)

The microphone detects if you are talking when using VOX/iVOX. If you are talking, the radio triggers transmission automatically.

- When iVOX is displayed, the radio uses the built-in microphone to detect your voice.
- When a VOX headset is connected to the radio, VOX is displayed and the headset microphone is used to detect your voice.

You can turn off or select the following settings to select the VOX/iVOX sensitivity level.

L3	High Sensitivity for quiet environments. Speaking softly is enough to trigger VOX/iVOX transmission.
L2	Medium Sensitivity for most environments
L1	Low Sensitivity for noisy environments. You must speak up to trigger VOX/iVOX transmission.

Note: Pressing the **PTT** button cancels the VOX/iVOX transmission.



MN007504A01-AB



<http://www.motorolasolutions.com/talkabout>

MOTOROLA, MOTO, MOTOROLA SOLUTIONS and the Stylized M logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC and are used under license. All other trademarks are the property of their respective owners.
© 2021 and 2022 Motorola Solutions, Inc. All rights reserved.
Printed in

